


WEEKLY PROGRAMMABLE TIMER




Timer

POWER

DIMENSIONS

7 _{16A}

No



60mm 21mm

54mm

DIN Rail Installation

Advanced pre-setting one week before

Digital electronic time switch with daily programs

Repeat programs with 16 on/off setting; and manual over-ride

Lithium battery power reserve

Auto time error correction ±60sec, weekly

Unlock instructions

Press the "C/R" button for the four time, and the " character disappears in the

lower left corner of the display screen. At this time, the control switch is to unlock the

state. All keys are valid, can be set or other operation. If not operated in 15 seconds, the time controlled switch is automatically locked. Such as finish setting up, you can also press the "C/R" button for four times, after manual lockbutton is invalid.

TECHNICAL DATA

Voltage rating: AC 220V 50/60Hz Voltage limit: AC 180V~250V

Hystresis: ≤1 sec/day(25°C)

ON/OFF operation:16 ON& 16 OFF Power consumption: 2VA (max) Display:LCD

Service life: Mechanial 107 Electrically 105

Minimum interval:1 minute Weight:approx 40g

Order voltage 12V, 24V, 36V, 48V, 110V; Count down: 1 sec-99 min 56 sec

Pulse:1 sec-59 min 59 sec Load capacity: resistive load:16A/25V AC

Lagging load: 10A/250Vac Lamp load:2000W Switching contact: 1 changeover switch Power reserve: 3 years (Lithium battery)

Ambient temperature:-10~+40℃ Ambient humidity: 35~85%RH \bigcirc


Digital Time Switch


В

 ϵ

WEEKLY PROGRAMMABLE ELECTRONIC TIMER

16A(8)A. 250AC





Operating Instruction

1. To start switch: press reset Key, At the first time, if you want to the present time, please press " On board, then press D+, H+, M+ to adjust the number to the present time.

Step	Key	Programming
1	Press P	Setting1 ON time(display 1on)
2	Press H+/M+	Setting hours and minutes
3	Press D+	To select same every day,or different time each day
4	Press P	Setting 1off time (display 1 off)
5	Press H+/M+	Setting hours and minutes turn off time
6	Press D+	If you want the same every day, you need not press this ke
7	Repeat step2-6	Set 2–16 on/off time
8	Press 🕒	End

If you do not require 16 settings, press "(-)" to the end.

■ NOTE:

Φ32×4

- 1. Time setting should according to the time sequence, couldn't be set crossly 2. System with quit automatically if there's no operating within 10 seconds and no
- data is saved. 3. Function 3,4,5 can not be used simultaneously.